



2011

BUILDER'S  
HARDWARE  
*Rusticware*



780 Single Blank



781 Single Cable



782 Single Switch




783 Single Receptacle




784 Single Rocker



785 Double Switch



786 Double Receptacle




787 Double Rocker



788 Double Rocker/Switch



789 Triple Switch



790 4-Gang



791 Double Switch/Recep

# SATIN NICKEL



750 - 4"



751 - 4"




752 - 4"



753 - 4"



754 - 4"



755 - 4"



756 - 4"



757 - 4"



758 - 4"



759 - 4"



780 Single Blank



781 Single Cable



782 Single Switch




783 Single Receptacle



784 Single Rocker



785 Double Switch



786 Double Receptacle




787 Double Rocker



788 Double Rocker/  
Switch



789 Triple Switch



790 4-Gang



791 Double Switch/Recept

# OIL RUBBED BRONZE




750 - 4"



751 - 4"



752 - 4"



753 - 4"




754 - 4"



755 - 4"



756 - 4"



757 - 4"



758 - 4"



759 - 4"

# DOORBELL BUTTONS

3 3/4"

LIGHTED  
IN OIL RUBBED BRONZE  
& SATIN NICKEL



770



10545 SOUTH MEMORIAL  
TULSA, OK 74133  
TOLL FREE 866.369.7878  
FAX 918.369.0601  
WWW.RUSTICWARE.COM